




E-20 SERIES

PARTS LIST

1. Stand
2. Housing
3. Bull Gear
4. Roller
5. Roller Cap
- 5A. Stop Block Cap
6. Pinion Assembly
7. Stop Block
8. Spindle
9. Nut
10. Bending Arm
11. Stop Arm
12. End Plates (2)
13. Tripper
14. Limit Switch & Bracket (3)
15. Roller Stud
16. Stop Block Stud
17. Roller Slide
18. Stop Block Slide
19. Roller Stud Bolt
- 19A. Stop Block Stud Bolt (2)
20. Latch Pin
21. Latch Plate
22. Push Button Station
23. Magnetic Starter
24. Motor
25. Link Assembly
- A. Bearing for Part 8
- B. Thrust Bearing Assembly

PEDRICK

Established 1875

Phone: (856) 829-8900
Fax: (856) 829-8902

Tool & Machine Company, Incorporated

• P.O. Box 190 • Riverton, New Jersey 08077
Web: <http://www.pedrick.com> • E-Mail: info@pedrick.com