



D-20 SERIES

PARTS LIST

- 1. Stand
- 2. Housing
- 3. Bull Gear
- 4. Roller
- 5. Roller Cap
- 5A. Stop Block Cap
- 6. Pinion Assembly
- 7. Stop Block
- 8. Spindle
- 9. Nut
- 10. Bending Arm
- 11. Stop Arm
- 12. End Plates (2)
- 13. Tripper
- 14. Limit Switch & Bracket (3)
- 15. Roller Stud
- 16. Stop Block Stud
- 17. Roller Slide
- 18. Stop Block Slide
- 19. Roller Stud Bolt
- 19A. Stop Block Stud Bolt (2)
- 20. Latch Pin
- 21. Latch Plate
- 22. Push Button Station
- 23. Magnetic Starter
- 24. Motor
- 25. Link Assembly
- A. Bearing for Part 8
- B. Thrust Bearing Assembly



Established 1875

Phone: (856) 829-8900
 Fax: (856) 829-8902

Tool & Machine Company, Incorporated

• P.O. Box 190 • Riverton, New Jersey 08077
 Web: <http://www.pedrick.com> • E-Mail: info@pedrick.com